

## Automate™ Rechargeable Motorization

---

### ADJUSTING Q3.0 & Q10.0 OPEN ROLL BRACKETS

---

The open roll brackets for the Automate Q3.0 and Q10.0 can be used for both ceiling and wall mount applications.

To adjust brackets for wall mount installation:

1. Remove screws and washers from mounting box on the inner side of the bracket. Set aside.
2. Remove box from bracket, rotate box  $\frac{1}{4}$  turn, reinsert box into notches on bracket.  
**Note:** Double check that boxes, both idle and motor ends, are facing the correct direction before reinserting.
3. Reinsert screws and washers into mounting box and reattach to bracket.
4. Repeat steps for opposite side bracket.